

CapTel® 2400i

For Internet-only Use (VoIP)



CapTel Acceptable Use Policy

The CapTel phone is intended for use by people with hearing loss. People who do not need captioning support should only use CapTel with the CAPTIONS feature turned off. Federal law prohibits anyone but registered users with hearing loss from using Internet Protocol (IP) Captioned Telephones with the captions turned on.

CapTel 2400i Specifications

Physical Dimensions

Size: 12.56" wide × 9.54" tall × 3.64" deep (Dimensions with the stand folded against the phone.)
Weight: 3 lbs. 2.3 oz.

Power

AC Adapter: 5.9-6.0V 3Amps
(barrel is negative)
Adapter is UL listed.

Dial Pad

Large keys: 0.62" × 0.56"

Display

10.1" Backlit, graphical LCD color display
1024 × 600 pixels
Resistive touch panel

Function Buttons

Volume
Speaker
Mute
Customer Service speed dial
Home
Captions

Controls

Conversation Amplification:
0–40dB gain
Tone: low, medium, high
Customizable to match personal audiogram

Model

CapTel 2400iSP-NBT-VOIP

Indicator Lights

Mute
Volume Levels (1 through 12)
Captions on/off
Ring Flasher

Handset

Type: HAC (Hearing Aid Compatible)
Amplification: 40dB gain
TIA-4953 Approved

Dialing

Phone Book (100 entries)
Favorites (10 entries)
Speed Dial (4 entries)
Redial (Last number dialed)

Captions

Nine (9) Caption font sizes:
Small
1 – 0.20" (5 mm)
2 – 0.23" (6 mm)
3 – 0.25" (6.5 mm)
Medium
4 – 0.30" (7 mm)
5 – 0.33" (9 mm)
6 – 0.48" (10.5 mm)
Large
7 – 0.51" (12 mm)
8 – 0.54" (13.5 mm)
9 – 0.90" (22 mm)
Adjustable colors for captions font and background
Five (5) font style options

Connections

Ethernet or WiFi wireless network
AC Power

Approvals

ACTA Product-Labeling Number:
US:D8KTE00BCAP2400
FCC ID: D8K-CAPTEL2400IS2
Contains FCC IDs:
YOPGS2101M, QOQWT12
FCC approved: Part 15B
TIA-4953 Approved Handset

Conversation Memory

360,000 characters (minimum of 10 hours of conversation per call)

Caller ID History

Info saved for last 100 calls

Answering Machine

100 recordable messages
Default or personalized greeting
Selectable number of rings before answer
Max message length: 90 seconds

NOTE: Your CapTel phone will periodically connect to the Captioning Service through the Internet connection to report its status and check for software updates.

Congratulations on Choosing *CapTel*!

Welcome to the Captioned Telephone – CapTel! With CapTel, you can see captions of everything people say over the phone, letting you enjoy calls with confidence.

Your CapTel phone is easy to use. It works just like any other phone. You can dial on the number keypad and listen on the handset. Or, you can use the easy touch screen display to make and answer calls. Whatever works best for you.

If you ever have any questions, please refer to this guide to learn:

- How to start using your CapTel 2400i
- How your CapTel 2400i works
- How to get help when you have questions

As you use your new phone, we welcome your questions and comments. Thank you for choosing the CapTel captioned telephone.

Sincerely,

CapTel Customer Service
1-888-269-7477
www.CapTel.com

T A B L E O F C O N T E N T S

	Overview – How CapTel Works.....	4
	Section 1: Getting Started	5
	What is in the box.....	5
	Overview of CapTel 2400i phone	6
	Setting up your CapTel 2400i	11
	Section 2: Making and Answering Calls	22
	Dialing a phone number directly	23
	Answering an incoming call.....	25
	Switching Captioning Method During a Call	26
	Turning captions on/off during a call	27
	Adjusting the volume	27
	Adjusting the Tone Control.....	28
	Customizing the Tone setting.....	29
	Using the Speakerphone.....	30
	Knowing what sounds are on the line	32
	Section 3: Viewing Captions	34
	Turning captions on/off during a call	35
	Viewing corrections.....	36
	Reviewing captions during a call.....	37
	Reviewing captions after hanging up.....	38
	Saving conversation captions.....	39
	Erasing captions.....	40
	Changing the color of the captions	41
	Changing the captions font size and style	43
	Setting how captions scroll across the Display Screen	44
	Adjusting the brightness of the Display Screen.....	45
	Section 4: Call History	46
	Reviewing previous calls	47
	Reviewing captions from a previous call	48
	Dialing from Call History.....	49
	Deleting previous calls	50



Section 5: Answering Machine 51

About the Answering Machine	52
Turning Answering Machine on/off	53
Playing your Answering Machine messages	54
Erasing Answering Machine messages	55
Deleting all messages	56
Recording a personal greeting	57
Remote Message Retrieval	59
Setting the ring count	62
Playing incoming messages aloud/silent	63



Section 6: Contacts 64

Adding a new contact	65
Dialing a phone number in your Contact List	66
Editing an existing contact	67
Removing a contact	68
Adding a contact to Speed Dial	69
Adding a photo to a contact	70



Section 7: Favorites 82

About Favorites	83
Adding a contact to Favorites	84
Dialing Favorites	85
Removing a contact from Favorites	85



Section 8: Settings 86

Setting the language	87	Saving conversation volume	92
Switching captions language	88	Keypad lights	92
Setting Default Language	89	Setting the ringer volume	92
Setting Display Brightness	90	Adjusting the ringer pitch	92
Screen timeout	90	Tone control	93
Night mode	90	Time Zone	93
Network	90	About your CapTel phone	93
Saving captions after hang up	91	Updating your software	93
Captions button	91	Advanced settings	94
Ring flasher	91		



Troubleshooting 95

Index 96

How CapTel Works



Your new CapTel 2400i works like any other phone – just pick up the handset and dial the person you want to call on the dialing keypad. Every time you make a call, the Internet connection acts as your telephone line, carrying your conversation back and forth. It also links to a Captioning Service that uses speech recognition technology to create captions of everything your caller says. The captions appear on your CapTel 2400i display screen for you to read.

You can enjoy conversations over the phone, with the added help of written captions.

NOTE *The CapTel 2400i phone does not generate captions of the phone call on its own. The phone works with the Captioning Service (over the Internet connection) to display captions during your calls.*

Getting Started

This section explains how to start using your new CapTel 2400i phone.

TOPICS

- **What is in the Box**
- **Overview of CapTel 2400i**
- **Setting up Your CapTel 2400i**

What is in the Box?

Your CapTel 2400i includes the following parts:



- CapTel 2400i VoIP Phone
- Power Adapter – to plug into a wall outlet



Important! Use only the power adapter that came in the box with your CapTel 2400i

- Ethernet Cable – to connect to Internet service (not necessary for WiFi installations)



- CapTel Setup Guide and CapTel User Manual



Overview of CapTel 2400i Phone



Please see the descriptions that correspond with the matching numbers on the next few pages to help explain what each feature is.



1 Touch Screen Display

Shows captions, Caller ID, Answering Machine messages, Contacts, and more. You can touch an item on the Display Screen to select it.



2 Time & Date



3 Ring Flasher

Bright lights blink to alert you to any incoming calls and new answering machine messages.



4 Settings

Lets you control and adjust the features of your phone.



5 Contacts

Allows you to store and quickly dial people you call often. Saves up to 100 contacts.



6 Favorites

Saves the phone number of people you call most often for quick and easy dialing.



7 Call History

Shows your most recent incoming and outgoing calls, plus lets you read captions from previous phone calls.



8 Answering Machine

Turns the Answering Machine on/off and lets you check messages – with captions.



9 Volume Button

Lets you adjust the volume to a comfortable level, up to a 40dB gain from min/max. To increase the volume, press plus sign **+** on the VOL button. Press minus sign **-** on the VOL button to decrease the volume. The indicator lights next to the volume bar indicate the volume setting.

WARNING

The maximum volume setting is extremely loud. People who do not need amplification should not use the phone at the highest volume level.

The volume returns to a mid-range setting every time you hang up the handset. To save your volume setting so that it will be used during every call, see “Saving Conversation Volume” on page 92.

- ## 10 Built-in Microphone

Speak directly toward the microphone when using the speakerphone.



11 SPEAKER Button

Lets you talk/listen over the built in speaker, to enjoy hands-free conversations.



12 Dialing Keypad

Use to dial telephone numbers – just like with any other phone.



13 HOME Button

Press the HOME button at any time to return to the main menu screen. The HOME button is your easy way to go back to the beginning and start again.

NOTE

If you are ever “lost” in the menu system, press the HOME button to return to the main screen.



14 CAPTIONS Button

When the CAPTIONS button is on (blue light around button is lit) you will see word-for-word captions of everything the other party says. Press the CAPTIONS button at any time during a call to turn captions on or off.



15 MUTE Button

Silences the sound from your end of the conversation. When the MUTE button is pressed (red light around the button is ON), the person on the other end of your call will not be able to hear you. You will still be able to hear the caller and get captions of everything they say. To turn the Mute feature off, press the MUTE button again (light around the button is OFF).



16 CUSTOMER SERVICE Button

Pressing the CUSTOMER SERVICE button will automatically dial the CapTel help line. Our helpful Customer Service team is happy to help you set up and use your CapTel 2400i phone – we're only a button push away.

NOTE

*Help is available 24 hours a day, 7 days a week (closed on major holidays).
Help materials are also available online at www.CapTel.com*

Back view of CapTel 2400i VoIP



1 Kickstand

Pull out and position the kickstand to find the most convenient angle for reading the CapTel display screen.

2 LNK/ACT – Status Light

Lets you know if your Ethernet cable is connected to the Internet and whether activity is on the line. NOTE: the LNK/ACT indicator does not light up when connected via WiFi.

3 Ethernet Jack

Plug the Ethernet cable (provided) here to connect to your Internet service. If you connect to the Internet using a WiFi network, you do not need to plug in the Ethernet cable.

4 Power Jack

Plug the AC power adapter here. Use only the AC power adapter that came with your CapTel 2400i phone. Any other adapter may damage the phone.

Setting up Your CapTel 2400i

Requirements

- 1. High-speed Internet access.** Your CapTel phone can connect to your Internet service either with an Ethernet cable (recommended) or through a wireless (WiFi) network. Depending on your Internet setup, a router may also be required to allow you to connect more than one device to your Internet service.
- 2. Standard electrical power** (AC adapter plugs into standard wall outlet).

Step 1: Activate & Register Your Phone

Per FCC requirements, you must first register your phone before the captions feature will be available. You also must activate your new phone for Internet-only (VoIP) service.

- Using a laptop, computer, or mobile device, go online to: www.CapTel.com/voip
- Click on “Activate Your Phone for Internet Phone Service”.

Activate Your Phone for Internet Phone Service

Then follow the instructions. Have your new phone handy, you will need information from the back of your phone to complete the process.

- When the registration/activation is complete, your phone will be assigned a new phone number.

TIP

Write your new phone number down and share it with people you talk to often, so that you can see captions when they call.

Step 2: Select a Location

Pull out the kickstand in the back, then set up the CapTel phone in a place where:

- A high-speed Internet (Ethernet) jack or your wireless router is located nearby.
- There is an electrical outlet nearby.
- The surface it will be set on is stable and secure.
- The area is protected from excessive heat or humidity.

NOTE


The outlets for power and the Ethernet connection should be located nearby, as each cord needs to plug into your CapTel phone. If your Internet access is located in a different room than where you plan to use the CapTel phone, a WiFi setup is recommended.

Step 3: Plug in the Power Adapter

1. Plug the power cord into the jack labeled “Power” on the back of the CapTel phone.
2. Plug the power adapter into a wall outlet or power strip. The display screen and Volume indicator lights will light up to let you know the power is connected.

WARNING:

Be sure to use only the power adapter that came with your CapTel 2400i. Using any other power adapter may damage your phone.




After a moment, the Initial Setup screen will appear. Follow the instructions on the display screen.


TIP To choose an option, touch the icon on the screen and then touch ➤ **(next)**.

Step 4: Select Language

1. Touch  (**English**) or  (**Espanol**) for the language you want.
2. Touch  (**next**) to continue.



Step 5: Network Connection




For Wired Connections (Recommended):

1. Plug the Ethernet cable that came with your phone into the jack on the back of the CapTel phone labeled "Ethernet".
2. Plug the other end of the Ethernet cable into the jack you use to access your Internet service. Depending on how your Internet service is set up, you could be plugging into an available Ethernet jack on any of the following:
 - On a digital cable modem
 - On a DSL modem
 - On a router in your home
 - In an Ethernet wall outlet


Use the examples on the following page to match your setting with the correct installation method.

All outlets located together (Wired Setup)

Example 1: All of the connection outlets (Internet and power) are available in the same room that you are planning to use the CapTel 2400i.



Example 2: If there is not an available Ethernet jack in your DSL or cable modem, you will need a router or switch that lets you connect more than one device to the Internet. Contact your Internet Service Provider to learn what router or switch will work with your modem. The router should support DHCP. Connect the router to your DSL/cable modem. Then connect the CapTel 2400i to the router or switch using the Ethernet cable.




For Wireless (WiFi) Connections:

If you have a wireless (WiFi) network in your home or office, your CapTel phone can connect to the Internet using the WiFi network. You do not need to plug in an Ethernet cable.

To set up your CapTel for WiFi use, you will need to know the name of your wireless network as well as any passwords that are needed to access the network. The way you access your WiFi network with CapTel will be very similar to how you access the network from a computer or mobile device.

NOTE


If someone helped install the wireless network for you, it may be helpful to consult with that person as you set up your CapTel phone.



1. Touch  **(Use WiFi Network)** on the display screen. CapTel scans for wireless networks within range of your phone.
2. The display lists any WiFi networks detected, in order of strongest signal strength to the weakest signal strength.

NOTE

CapTel may detect wireless networks in your location that you do not recognize – such as a wireless network from a neighbor or nearby office. Be sure to select the name that matches your own network.



3. Touch the name of the network that you want to use.

Then touch **(Connect)**.

If you do not see the network you want to use:

- Try moving your CapTel phone to an area closer to your wireless router. Then, touch **(Refresh)**. CapTel will re-scan for available networks.
- Touch **(Enter Manually)**. CapTel will ask you to enter information about your wireless network, then it will try to connect.

4. **Enter WiFi Password:** On the display, use the onscreen keyboard to enter the password for your WiFi network.



TIP


Remember to use the **(shift)** key for capital letters when needed. Passwords are case-sensitive. To enter special characters, touch **(Numbers)**.

When you are done, review your password carefully. If it does not exactly match the password for your network, CapTel will not be able to connect. Use the  key to correct any errors.

When you are satisfied the password is correct, touch  **(save)**.

Step 6: Time and Date


Touch the Time Zone on the display screen that you live in. Be sure to indicate if your Time Zone practices Daylight Savings Time (DTS). Touch  **(next)** to continue.



Your CapTel phone will fill in the date and time based on the time zone you indicate.

Step 7: Software

Your new phone checks to make sure that you have the most current software available. If needed, CapTel will automatically download the most recent software version. Please be patient, the download may take a few moments. Watch the progress on the CapTel display screen to know the status.




NOTE

Do not interrupt the power supply during a software installation. It may damage your CapTel phone.


Once the software download is complete, your CapTel phone will re-boot as part of the update process. It will automatically run through the setup steps again.

Congratulations! Your phone is registered and the Captions feature is enabled.



NOTE: Registration Incomplete

If your phone screen indicates registration is incomplete, please go online to www.CapTel.com/voip to activate and register your phone.



Step 8: Captioning Method

Your CapTel phone is equipped with SmartCaptions™ technology that automatically uses the best captioning method for your calling conditions. SmartCaptions is the default captions mode.



If you prefer, you can change the default captioning method to enhanced Assisted Captions or to fully-automated Auto Captions. You can also switch captioning methods during a call.

To learn more about the different captioning methods and how to change your default setting, visit www.captel.com/captions-mode.

NOTE

911 Calls are given priority and will be processed using Assisted Captions once an operator is available. CapTel may adjust the captioning method of any call under certain circumstances, to provide the best possible captioning experience.

Making and Answering Calls




This section explains how to place outgoing calls and how to answer incoming calls.

TOPICS


- **Dialing a Phone Number Directly**
- **Answering an Incoming Call**
- **Turning Captions On/Off during a Call**
- **Adjusting the Volume**
- **Adjusting the Tone Control**
- **Customizing the Tone Setting**
- **Using the Speakerphone**
- **Knowing What Sounds are on the Line**


Dialing a Phone Number Directly



Like with any other phone, you can dial the phone number of the person you want to call.

1. Before you dial, check that the blue light around the  (**CAPTIONS button**) is on. If not, press the CAPTIONS button to turn captions on.
2. Lift the handset. Or, to make a call using the speakerphone, press  (**SPEAKER button**).
3. Use the CapTel dialing keypad  to dial the phone number of the person you wish to call.
4. As you dial, the display screen shows the status as your CapTel phone connects to the captioning service.





5. Listen or watch the display screen to know when someone answers. Begin your conversation as you normally would. Captions will appear on the display screen as the other party speaks.

You can adjust the volume during the call to a level you hear best by pressing **+** (plus) or **-** (minus) on the **VOL button**.

When you are finished with your call, hang up the handset.

TIP

You can turn captions on/off at any point in the call. Just press the CAPTIONS button. When the blue light is on, you will get captions.

TIP

Talk back and forth as you normally would, reading the captions as you go. You don't need to wait for the captions to finish appearing on screen before you answer.


NOTE

You can also place a call to someone listed in your Contacts, Favorites, Call History, or Speed Dial settings. You need to have entries saved in Contacts before you can use these features. See Contacts on page 64 for instructions.


TIP

When you place a call, CapTel can automatically redial the last number dialed. When you lift the handset, simply touch the "Redial" icon on the screen. CapTel will dial the number automatically.

Answering an Incoming Call




1. When the phone rings, the display lights up to let you know there is an incoming call. (If you have Caller ID service, the caller's name and phone number will appear.)
2. Lift up the handset to answer the call. Or, to answer on speakerphone, press  (**SPEAKER button**).
3. Check that the blue light around the  (**CAPTIONS button**) is on. If not, press the CAPTIONS button to turn captions on.



When you are finished with your conversation, hang up the phone as you normally would.

Switching Captioning Method During a Call



Your CapTel phone features SmartCaptions™ technology that automatically uses the best captioning method based on calling conditions. You can also manually switch captioning methods during a call. Captions are generated two ways:

Auto Captions: captions are entirely computer-generated.

Assisted Captions: a Captioning Assistant (CA) adds corrections and call details (i.e., background sounds).

To change the Captioning Method:

1. During a call, touch  (**Options**).
2. The screen shows which Caption Mode is used. Touch  (**Switch to CA**) to change modes.
3. Touch  (**Back**) to return to the conversation.

Once you hang up at the end of the call, the next call you make or receive will start using the default Captioning Preference again.

To learn more about the captioning methods, visit captel.com/captions-mode.

NOTE *To change your Captioning Preference default setting, press the blue button to contact CapTel Customer Service for assistance.*

Turning Captions On/Off During a Call

You can turn captions on/off at any time during your call by pressing  (**CAPTIONS button**). When the blue light around the CAPTIONS button is lit, you will see captions of everything the other party says.

To turn captions off, press  (**CAPTIONS button**) again. The blue light around the CAPTIONS button goes off.

NOTE: Federal law prohibits anyone but registered users with hearing loss from using Internet Protocol (IP) Captioned Telephones with the captions turned on.

Adjusting the Volume

You can increase the volume of the person's voice coming through the handset or speakerphone, up to a 40dB gain from min/max. Watch the lights next to the VOL bar to see what level the volume is set to.


- To increase the volume, press  on the **VOL button**.
- To decrease the volume, press  on the **VOL button**.

NOTE

The maximum volume setting is very loud. People who do not need amplification should not use the phone at its highest volume setting. The volume level automatically returns to a mid-range setting whenever the phone is hung up.

To save your volume setting so that it will be used during every call, see "Saving Conversation Volume" on page 92.

Adjusting the Tone Control



You can adjust the Tone of the handset sound to a frequency range that is better to hear. Use the Tone setting to emphasize HIGH, MEDIUM, or LOW frequency sound ranges. You can even customize the sound frequency to match your own audiogram. The setting will remain in effect until you change it again.

You can adjust the Tone setting before, during, or after a call.

To adjust the Tone setting:

1. On the display screen, touch  (**Settings**).
2. Touch  (**Sounds**).
3. Touch  (**Tone**).
4. The display shows what the current setting is: LOW, MED, HIGH, or CUSTOM.
5. Touch the Tone setting you wish to use.


TIP

To test how the Tone setting will sound, lift the handset and press  on the display screen. You will hear a recording of first a man's and then a woman's voice, letting you check if the setting makes it easier to hear. Experiment with the different Tone settings to find the range that works best.

NOTE

During a call: touch  (**Options**) to adjust to a different Tone setting that you hear best.

Customizing the Tone Setting



Your CapTel phone lets you personalize the Tone setting to enhance the frequency ranges that you hear best. For example, you can adjust the tone settings to match your own personal audiogram. CapTel lets you listen to test each setting as you make changes, to find the optimal customized hearing level.

To customize the Tone setting:

1. On the display screen, touch (**Settings**).
2. Touch (**Sounds**).
3. Touch (**Tone**).
4. On the display screen, touch (**Custom**).
5. Touch and drag the blue circles on the frequency chart to adjust the various sound levels.

As you make changes, test the sound quality by touching (**play**) while listening over the handset.

TIP *If you have a personal audiogram, adjust the blue circles to match the shape of your audiogram to give you optimal sound levels for your personal hearing level.*

6. When you are finished, hang up the handset and touch (**Accept**) to save your changes or (**Cancel**) to exit.

Using the Speakerphone

Turning the Speakerphone On

At any point before or during a call, press the  (**SPEAKER button**) on the CapTel dialing pad to turn the speakerphone on (light on SPEAKER button goes ON). The CapTel handset will turn off, and any sounds on the line will be amplified out loud over the CapTel speaker.

TIP

When the speakerphone is on, talk as you normally would directly facing the front of your CapTel phone. You do not need to speak into the CapTel handset. As long as you directly face the CapTel display screen, the microphone will pick up your speech for your caller to hear.

When the speakerphone is on you can set down or hang up the CapTel handset without ending the call. The conversation will be carried on over the speakerphone and captions of your call will appear on the display screen.

Turning the Speakerphone Off

You can alternate between using the speakerphone or using the CapTel handset during your calls, by turning the speakerphone on and off. The way you turn the speakerphone off depends on whether the CapTel handset is hung up or not.

If the CapTel handset is lifted (not hung up):

Press the  (**SPEAKER button**) on the CapTel dialing pad to turn the speakerphone off. The light on the speakerphone button will go off and the sound will be directed to the CapTel handset for you to continue the call.

If the CapTel handset is hung up and you'd like to continue the call:

Lift the CapTel handset. The speakerphone will go off and the sound will be directed to the CapTel handset for you to continue the call.

If the CapTel handset is hung up and you'd like to end the call:

Press the  (**SPEAKER button**) on the CapTel dialing pad. The speakerphone will go off and the call will end.

Ending a Call when the Speakerphone is On

The way to end a call when the speakerphone is on depends on whether the CapTel handset is hung up or not.

If the CapTel handset is hung up:

Press the  (**SPEAKER button**) on the CapTel dialing pad. The speakerphone will turn off and the call will end.


If the CapTel handset is lifted (not hung up):

Hang up the handset, as you would end with any other call. If needed, press the  (**SPEAKER button**) to turn the speakerphone off. The speakerphone will turn off and the call will end.

Adjusting the Sound on the Speakerphone

Use the volume key to adjust the volume of the sound coming out of the speakerphone.

Knowing What Sounds are on the Line



The handset graphic on the display screen tells you what incoming and outgoing sounds are occurring during your call with two visual indicators: the Signal meter (yellow waves) and the Outgoing Volume meter (blue waves).



Signal Meter – Sounds on the Line

Shows when there is sound coming over the line, even if the sound is not loud enough for you to hear. The more sound waves coming out of the handset, the louder the sound.



Outgoing Volume Meter

Helps you to see how loudly you are speaking. The more lines going into the handset/MIC graphic, the louder your voice is. If the lines become red, you may want to lower the volume of your own voice during a call.

TIP

The display shows whether sound is coming over the CapTel headset  or over the speakerphone .

NOTE

These meters only appear during calls that have captions.

Getting Help

If you have any questions as you use your new CapTel 2400i, we're here to help. Use any of these ways to contact us:

Pick up the handset and press  **(CUSTOMER SERVICE button)** to automatically speed dial directly to our helpful Customer Service team. If you are in an office setting, you may need to dial a number such as "9" first to get an outside line first and then press  **(CUSTOMER SERVICE button)**. *(Available 24 hours a day, 7 days a week. Customer Service is closed on major holidays.)*

Help materials are also available online at our website.



Phone: 1-888-269-7477 *(Available 24 hours a day, 7 days a week)*

FAX: (608) 204-6167



Mail: CapTel Customer Service
450 Science Drive
Madison, WI 53711



Email: CapTel@CapTel.com

Online: www.CapTel.com
(Live Chat help available at our website)

Spanish Language Customer Service: 1-866-670-9134

Viewing Captions




This section explains how to adjust and review conversation captions.

TOPICS

- **Turning Captions On/Off During a Call**
- **Viewing Corrections**
- **Reviewing Captions During a Call**
- **Reviewing Captions After Hanging Up**
- **Saving Conversation Captions**
- **Erasing Captions**
- **Changing the Color of the Captions**
- **Changing the Captions Font Size and Style**
- **Setting how Captions Scroll Across the Display Screen**
- **Adjusting the Brightness of the Display Screen**

Turning Captions On/Off During a Call



You can turn captions on/off at any time during your call by pressing  (**CAPTIONS button**). When the blue light around the CAPTIONS button is lit, you will see captions of everything the other party says.


To turn captions off, press  (**CAPTIONS button**). The blue light around the CAPTIONS button goes off.

NOTE You can increase/decrease the size of the captions font by touching  or  at the bottom of the screen.

TIP You can press the CAPTIONS button at any time during the call. If captions are not on at the start of your call, don't worry. Captions will appear shortly after the CAPTIONS button is turned on.

NOTE: Federal law prohibits anyone but registered users with hearing loss from using Internet Protocol (IP) Captioned Telephones with the captions turned on.

Viewing Corrections




On occasion, word errors may appear in the captions due to the speech recognition system the Captioning Service uses. The Captioning Service will try to correct word errors as they occur. The corrected word may appear in a different color than the rest of the captions to let you know a correction has been made.

There may be a slight delay before the word error is corrected. If you are unclear about what was said, ask your caller to clarify.

You can select which color you'd like the corrected word(s) to appear in. Please see "Changing the Color of the Captions" on page 41.

NOTE Corrections only appear when you are in Assisted Captions mode.

Reviewing Captions During a Call



To review captions during a call:

1. Touch  (**Pause Captions**).

2. Then:

A: Touch and move the slide bar at the right up to scroll back through previous captions.

– OR –


B: Place your finger on the captions screen and swipe downward to review previous captions.

When you are finished reviewing captions, touch  (**Back to Live Captions**) to return to the current conversation. Anything the other party said during the time you were reviewing captions will appear, and the live captions will continue as usual.

NOTE

Your CapTel phone holds captions for up to 100 different conversations in memory (approximately 10 hours of conversations). If the conversation memory fills up entirely, older captions will be erased as new captions come in.

Reviewing Captions After Hanging Up




To review captions after your conversation is ended and the phone is hung up:

1. On the display screen, touch  (**Call History**).
2. From the Call History listing on the left, touch the call that you wish to review. If needed, use the scroll bar or touch  and  to scroll through the list of calls.
3. Once the call you want is highlighted, information about the call appears on the right. Touch  (**review captions**) to review captions of the call. When reviewing captions: Touch and drag the scroll bar on the right to move backwards and forwards through captions. Touch  and  to see captions from a previous/later call.
4. When you are done reviewing captions, press  (**HOME button**) to exit.

TIP The Call History listing lets you know whether a call was  **incoming** or  **outgoing**.

NOTE Your CapTel phone comes with the Save Captions feature enabled, letting you view conversation captions after you've hung up the phone. You can turn this feature off so that CapTel will not save conversation captions after every call. Please see *Saving Captions after Hang up* on page 91 for instructions.

Saving Conversation Captions



You can set your CapTel phone to save captions after the call is ended. This allows you to go back and review what was said after you've hung up. You can review captions from up to 100 different conversations in memory. The default setting is Save Captions – ON.

To change the Save Captions setting:


1. On the display screen, touch  (**Settings**).
2. Touch  (**General Settings**).
3. Touch  (**Save Captions On**).
4. Touch  (**On**) or  (**Off**) to select.

Save Captions On saves conversation captions after the call is finished and the phone is hung up.

Save Captions Off erases the conversation captions after every call.

5. Once you have made your selection, press  (**HOME button**) to exit.

Erasing Captions



To erase captions of a single conversation after the call has ended:

1. From the display screen, touch  (**Call History**).
2. From the list on the left, touch the call that you want to review.

TIP *Touch and drag the scroll bar to see calls further up or down the list. You can use  (**Next/Prev**) to move up or down the list.*

3. Information about the call you selected appears in the right of the display.
4. Touch  (**Delete**) to delete this call from your Call History.
5. The display asks you to confirm if you want to delete the call. Touch  (**yes**) to delete or touch  (**no**) to exit.
6. When you are finished, press  (**HOME button**) to exit.

To erase all captions from Call History:

1. From the display screen, touch  (**Call History**).
2. Touch  (**Delete All**).
3. The display asks you to confirm if you want to delete all of your call history. Touch  (**yes**) to delete all call history entries, or touch  (**no**) to exit.
4. When you are finished, press  (**HOME button**) to exit.

Changing the Color of the Captions



You can change the color of the captions font and background color on the display screen to a color combination that you prefer. You need to set the conversation colors before or after a call. You cannot change the captions colors during a live captioned call.

NOTE *Changing the font color applies only to conversation captions. The font size and style for your CapTel 2400i menu options always remains the same.*

To change the font and background colors:

1. On the display screen, touch  **(Settings)**.
2. Touch  **(Display)**.
3. Touch  **(Display Colors)**.

4. The display screen shows you an example of how the colors are currently set.

To change the Captions color:

1. Make sure  (**Captions**) is highlighted (blue).
2. In the Color Options table, touch the color that you would like the captions to appear. As you select your color, CapTel shows you an example of how the captions will look.

To change the Background color:

1. Touch  (**Background**) to highlight (blue).
2. In the Color Options table, touch the color that you would like the background to appear. As you select your color, CapTel shows you an example of how the background will look.

To change the Corrections color:

1. Touch  (**Corrections**) to highlight (blue).
2. In the Color Options table, touch the color that you would like the Corrections to appear. As you select your color, CapTel shows you an example of how the corrections will look.

5. When you have selected the color combination that you prefer, touch  (**Accept**) to save or  (**Cancel**) to exit.

6. When you are done, press  (**HOME button**) to exit.

TIP

If you have difficulty reading the captions, you may try different color combinations to create higher contrast between the captions color and the background color.

Changing the Captions Font Size and Style




You can adjust the font size and style of the conversation captions to make them easier to read.

NOTE *Changing the font size or style only applies to conversation captions. The font size and style for your CapTel menu options always remains the same.*

To change the font size of the captions:

1. With the handset hung up, touch  (**Settings**).
2. Touch  (**Display**).
3. Touch  (**Font Settings**).
4. The display shows you what the current font size and style setting is.
To change the font style, touch one of the five (5) style options available.
To change the font size, touch  or .
5. When you have selected the font size and style that you prefer, touch  (**Accept**) to save your change or  (**Cancel**) to exit.
6. When you are done, press  (**HOME button**) to exit.

Setting how Captions Scroll Across the Display Screen



You can control how the captions appear on the display screen: either appearing word-by-word across the screen as each word is captioned or by smooth scrolling one line at a time in a continuous movement. The default setting is smooth scrolling.

To change the way captions scroll across the screen:


1. On the display screen, touch  (**Settings**).
2. Touch  (**General Settings**).
3. Touch  (**Smooth Scrolling**).
4. Touch the scrolling option that you prefer.

Line-by-Line Scrolling: captions appear word-by-word across the screen as they are captioned

Smooth Scrolling: captions appear one line at a time in a continuous motion

5. Once you have made your selection, press  (**HOME button**) to exit.

Adjusting the Brightness of the Display Screen



You can adjust the brightness of your CapTel display screen to make it easier to read in well-lit or dimly-lit environments.

NOTE *You need to adjust the brightness of the Display Screen before or after a call. You cannot set the display screen brightness during a live captioned call.*

To adjust the brightness of the Display Screen:

1. On the display screen, touch  (**Settings**).
2. Touch  (**Display**).
3. Touch  (**Brightness**).
4. Touch and drag the slide bar to adjust the brightness to the setting that you would like. Sliding left makes the display screen dimmer. Slide right to make the display screen brighter.
5. When the brightness is set, touch  (**Accept**) to save or  (**Cancel**) to exit.
6. Press  (**HOME button**) to exit.

NOTE *After 60 seconds of non-use, the CapTel display screen will start becoming more dim and gradually go completely dark as an energy-saving measure. To re-illuminate the screen, simply touch the display screen or any button on the dialing keypad.*

Call History




This section explains how to use Call History to see who has called you, to review captions of past conversations, and to see information about any incoming calls you may have missed.

TOPICS

- **Reviewing Previous Calls**
- **Reviewing Captions from a Previous Call**
- **Dialing from Call History**
- **Deleting Previous Calls**

About Call History

An indicator on the CapTel display screen shows you how many new calls are in your Call History list that you have not yet reviewed. When you touch  (**Call History**) and see the list of calls, the blue indicator resets so that it only shows the number of new calls that you have not yet seen.




New calls indicator

The number of calls in Call History may be different than the number of Answering Machine messages you have, as some callers may choose not to leave a message.

Reviewing Previous Calls

Your CapTel phone keeps a list of information about recent calls, including calls that you may have missed. You can review captions from the call, the date and time of the call, and any Caller ID information if available. CapTel can even show you a picture of the caller if it is someone in your Contact list.



- ❶ Previous calls: Touch the call you want information about.
- ❷ Information about the call shows up here.
- ❸ Indicates whether call was incoming, outgoing, or unanswered.
- ❹ Date and time of the call.
- ❺ Use the scroll bar to review entries further down the list.
- ❻ Next/Previous: Lets you move up/down through entries in the list.
- ❼ Delete all: Erases all calls in Call History.
- ❽ Delete: Erases the selected call from Call History.
- ❾ Review captions: Review captions of the call.
- ❿ Call: Places a call to this person.
- ⓫ Add to Contacts: Adds caller to your Contacts list.

TIP

Remember to first touch the call listed in Call History on the left side of display that you want to review. Once you touch the call listing, more information about the call appears on the right of your screen, including a picture of the caller if you have added a picture for him/her in your Contacts list.

Reviewing Captions from a Previous Call



You can look back and see captions from any call in your Call History.

To review captions from a previous call:

1. From the display screen, touch  (**Call History**).
2. From the list on the left, touch the call that you want to review.


TIP Touch and drag the scroll bar to see calls further up or down the list. You can use  (**Next/Prev**) to move up or down the list.

3. Information about the call that you selected appears in the right of the screen.
4. Touch  (**Review Captions**) to review captions of the call. If the call was not captioned originally, the display indicates “this call has no captions”.
5. Touch and drag the scroll bar at the right to move backwards and forwards through the captions.
6. When you are finished, press  (**HOME button**) to exit.

NOTE You can increase/decrease the size of the captions font by touching  or  at the bottom of the display.

NOTE Touch   (**<<prev / next>>**) to view captions from a previous/later call.

Dialing from Call History



You can use Call History to quickly re-dial someone that has called you before. This is especially helpful if you notice you've missed a call – you can call the person back directly from Call History.

To dial a number from Call History:


1. From the display screen, touch  (**Call History**).
2. From the list on the left, touch the call that you want to review.

TIP Touch and drag the scroll bar to see calls further up or down the list. You can use  (**Next/Previous**) to move up or down the list.

3. Information about the call that you selected appears in the right of the screen.
4. Touch  (**Call**) to place a call to this person.
5. If you are calling this number for the first time, the display asks you to select which format to use when dialing the phone number. For example, does CapTel need to dial a 1 or the area code first? Touch the correct number format (yellow indicator lights up).
6. Lift the handset. CapTel dials the number automatically.

NOTE You can add a caller from your Call History to your Contacts list for easy dialing. Touch  (**add to contacts**) to confirm the number format and enter the new Contact's name.

Deleting Previous Calls



To delete a single call from Call History:

1. From the display screen, touch  (**Call History**).
2. From the list on the left, touch the call that you want to review.

TIP *Touch and drag the scroll bar to see calls further up or down the list. You can use  (**Next/Prev**) to move up or down the list.*

3. Information about the call you selected appears in the right of the display.
4. Touch  (**Delete**) to delete this call from your Call History.
5. The display asks you to confirm if you want to delete the call. Touch  (**yes**) to delete or touch  (**no**) to exit.
6. When you are finished, press  (**HOME button**) to exit.

To delete all calls from Call History:

1. From the display screen, touch  (**Call History**).
2. Touch  (**Delete All**).
3. The display asks you to confirm if you want to delete all of your call history. Touch  (**yes**) to delete all call history entries, or touch  (**no**) to exit.
4. When you are finished, press  (**HOME button**) to exit.

Answering Machine




This section explains how to use the built-in Answering Machine and see captions of messages that people leave for you. You can hear the voice recording and read captions of the message. You can also retrieve your Answering Machine messages remotely from a different phone.

TOPICS

- **About the Answering Machine**
- **Turning Answering Machine On/Off**
- **Playing Your Answering Machine Messages**
- **Erasing Answering Machine Messages**
- **Deleting All Messages**
- **Recording a Personal Greeting**
- **Remote Message Retrieval**
- **Setting the Ring Count**
- **Playing Incoming Messages Aloud/Silent**


About the Answering Machine



Your CapTel phone can take messages for you when you are unavailable, for you to play back later. When checking your messages, you can listen to the messages as well as read captions. The CapTel Answering Machine saves up to 100 messages. Each message can be up to 90 seconds long.

If you have more than one answering machine in your home or office, make sure only one answering machine device is turned on/active at a time.

Turning Answering Machine On/Off



To turn Answering Machine on:

1. The first time you set up your Answering Machine: on the display screen, touch  (**Ans Machine**).
2. The display screen shows you the current setting (on or off). Touch  (**yes**) to turn the Answering Machine on.


TIP A green  **on** indicator appears on the Answering Machine icon to let you know at a glance whenever the Answering Machine is turned on.

NOTE After the first instance, turn Answering Machine on by touching  (**Settings**),  (**Messages**), then  (**Answering Machine off**).

To turn Answering Machine off:

1. From the display screen, touch  (**Settings**).
2. Touch  (**Messages**).
3. Touch  (**Answering Machine On**).
4. The display asks you if you want the **answering machine on or off?** Touch  (**off**).
5. When you are finished press  (**HOME button**) to exit.

Playing Your Answering Machine Messages




1. The display screen indicates unread messages waiting.
2. Touch  (**Ans Machine**).
3. A list of your messages appears on the left of the display, with the most recent call highlighted. Select and touch the message you want to review.
4. Information about the highlighted call appears on the right of the display.
5. Touch  (**PLAY**). Your message plays aloud while captions appear on the display. You can lift the CapTel handset to listen over the handset instead of playing the message aloud.
6. When you are done listening/reading messages, you can:
 - Touch  (**<<prev / next>>**) to view captions from a previous/ later message. Messages are in date received order, most recent first.
 - Touch  (**Call**) to place a call to this person.
 - Touch  (**Delete**) to erase the Answering Machine message and captions.
 - Touch  (**re-caption**) to get new captions of this message.
 - Touch  (**PLAY**) to play the message/captions again.



If you play your message and there are no captions, press the CAPTIONS button (blue light on). The voice message will play again, showing captions.

TIP *If you are playing your Answering Machine messages, and an incoming call occurs, you can send the call directly to the Answering Machine to listen to it later.*

Erasing Answering Machine Messages




To erase an individual Answering Machine message:

1. The display screen lets you know when you have unread messages waiting.
2. Touch  (**Ans Machine**).
3. Select and touch the call you want to review from the Answering Machine list on the left side of the display. The most recent call is highlighted.
4. Information about the call you selected appears on the right side of the display.
5. Touch  (**PLAY**) to listen to your message and see the captions.
6. To delete the message, touch  (**Delete**). The display asks you to confirm you want to delete the message. Touch  (**yes**) to delete or touch  (**no**) to cancel.

When you are finished erasing your messages, press  (**HOME button**) to exit.

NOTE *In addition to erasing messages one at a time, you can delete all calls at once. See page 56 for instructions.*

Deleting All Messages



In addition to erasing Answering Machine messages one at a time as you play them, you can also erase all your saved Answering Machine messages at one time.

To delete all your Answering Machine messages:

1. From the display screen, touch  (**Settings**).
2. Touch  (**Messages**).
3. Touch  (**Delete All Messages**).
4. The display asks you to confirm you want to **delete ALL messages**.
Touch  (**yes**) to delete or touch  (**no**) to cancel.
5. Press  (**HOME button**) to exit.

Recording a Personal Greeting




You can record a personal greeting for your CapTel phone to use whenever the Answering Machine takes messages. If you do not want to record a personal greeting, the Answering Machine will use a pre-recorded greeting that says: *"Hello. No one is available to take your call. Please leave a message after the tone."*

To record a personal greeting:

1. From the display screen, touch  (**Settings**).
2. Touch  (**Messages**).
3. Touch  (**Greeting Message**).

TIP To hear the greeting that is currently being used, lift the handset or press  (**Speaker button**) and touch  (**play greeting message**). You will be able to hear the current greeting over the speaker or in the CapTel handset.

4. Touch  (**record new greeting**) to record your personal message.




5. Lift the CapTel handset and touch  (**press to start recording**).
6. Speaking into the CapTel handset, record the personal greeting you would like the Answering Machine to use. When you are finished recording, touch  (**press to stop recording**).

NOTE *You can also record a greeting by pressing the Speaker button instead of using the CapTel handset.*

7. If you are not satisfied with your personal greeting, you can re-record it. Just repeat steps 3–5 above.
8. When you are satisfied with your personal greeting, touch  (**Accept**). Hang up the CapTel handset.
9. Press  (**HOME button**) to exit.

Remote Message Retrieval



CapTel lets you call in to play your Answering Machine messages when you are away from your home or office. This feature must be turned on and you must set a personal identification number (PIN) for security before this feature will work.

The default setting for Remote Access is OFF.


NOTE

If possible, use a different CapTel phone when calling in to retrieve your messages, in order to be able to see captions of the messages. If you call using any other phone, you will be able to listen to the voice part of the Answering Machine messages but you will not be able to read captions at your remote location.

To turn Remote Message Retrieval on:

1. From the display screen, touch  **(Settings)**.
2. Touch  **(Messages)**.
3. Touch  **(Remote Access off)**.
4. Touch  **(On)** or  **(Off)** to select.


5. CapTel shows the default 4-digit Remote Access PIN. This is the number you need to enter when calling in remotely to play your Answering Machine messages.



You should change the PIN to a different number for your own use. Touch the four digits on the display screen that you want to use. The selected PIN appears on screen to confirm your selection.

TIP Be sure to write your PIN down for your own reference.

6. When you have the PIN that you want, touch  (**save**).
7. CapTel confirms the PIN number you have saved and shows a list of remote access commands. Use these commands when calling in to get your messages remotely.



8. When you are finished, press  (**HOME button**) to exit.

To Access Your Answering Machine Messages Remotely

1. From a different phone, call your own CapTel phone number and let it ring until the Answering Machine greeting begins.
2. Once you hear/read the BEEP, enter your 4-digit PIN by pressing keys on the dial pad of the phone that you are calling from.
3. Your CapTel 2400i will start playing aloud any recorded messages (starting with the most recent one) for you to hear. If you are calling from a different CapTel phone, you will be able to see captions of the messages while they are played.

After each message is played, there is a pause that lets you enter one of the following commands on the phone's dial pad:

Press 1 – Play Message
Press 2 – Go to Next Message
Press 3 – Delete Message
Press 4 – Exit Remote Access


If you do not press any of the dial pad keys, after 30 seconds your CapTel 2400i will automatically hang up.

4. When you are done, hang up the phone you are calling from.

TIP

If possible, use a different CapTel phone when calling in to retrieve your messages, in order to be able to see captions of the messages. If you call using any other phone, you will be able to listen to the voice part of the Answering Machine message but you will not be able to read captions at your remote location.

Setting the Ring Count




You can set the approximate number of times the CapTel will ring before the Answering Machine answers the call. The default setting is four (4) rings, but you can set it to be any number of rings between two (2) and nine (9).

NOTE *The ring count may be slightly different in telephone systems that use “distinctive” ring patterns. Please experiment with this setting as needed for your specific telephone system.*

To set the number of rings before answering:

1. From the display screen, touch  (**Settings**).
2. Touch  (**Messages**).
3. Touch  (**Set Ring Count**).
4. Touch the  (**arrows**) to select the number of rings you'd like to use, then touch  (**Accept**).
5. Press  (**HOME button**) to exit.

Playing Incoming Messages Aloud/Silent



Just like with other Answering Machines, you can “screen” callers by having incoming messages played aloud on the CapTel phone for before you answer the call. While this is a convenient feature, there may be times when you do not want incoming messages to be played aloud, but instead recorded silently for you to review at a later time. The default setting is for incoming messages to be muted (silent).

To make incoming calls audible or set them to be silent:

1. From the display screen, touch  (**Settings**).
2. Touch  (**Messages**).
3. Touch  (**External Speaker Off**).
4. The display asks if you want to  (**turn on**) or  (**turn off**) the answering machine speaker. Touch the option you want.
5. Press  (**HOME button**) to exit.

TIP You can “screen” incoming Answering Machine messages by listening to the caller and reading the captions while the message is recorded. Make sure that the Answering Machine Speaker is set to “On”. If you choose to answer the call, just pick up the handset and begin talking.

TIP You can also send an incoming call directly to the answering machine to take a message if you are busy. Just touch  (**Send to Ans Machine**).

Contacts



This section explains how to save frequently called numbers in your contact list for easy and quick dialing.

TOPICS

- **Adding a New Contact**
- **Dialing a Phone Number in Your Contact List**
- **Editing an Existing Contact**
- **Removing a Contact**
- **Adding a Contact to Speed Dial**
- **Adding a Photo to a Contact**

Adding a New Contact



You can save up to 100 names in your contact list for quick and easy dialing.

To add a new contact:

1. From the display screen, touch  (**Contacts**).
2. Touch  (**add new contact**).
3. Use the on-screen keyboard to type in the First Name of the person you want to add.
4. Touch the field next to “**Last**” to move down, then use the on-screen keyboard to enter the last name of the person.
5. You can be specific about which number(s) you are adding:  (**Mobile**),  (**Home**), or  (**Work**). Touch the field(s) next to the number(s) you’d like to add to begin entering.
6. When you are finished entering the Contacts information, touch  (**save**). The new contact appears on the left side of your Contacts list.
7. When you are finished, press  (**HOME button**) to exit.

TIP You can add a photograph of your contact person to each entry. Pictures can be entered at the MyContacts website, then synced to your phone. See *Adding a Photo to a Contact* on page 78 for instructions.

TIP You can add contacts to your Speed Dial or Favorites list. See pages 69 and 82 for instructions.

Dialing a Phone Number in Your Contact List



To easily dial someone in your contact list:

1. From the display screen, touch  (**Contacts**).
2. Under the Contacts list on the left side of the display, find and touch the name of the contact you wish to call. To see contacts further down the list, touch and drag the scroll bar.

TIP Touch  (**Next/Previous**) to move up/down through entries in your Contacts list.

3. On the right side of the display, touch the phone number of the person you want to call:  (**Mobile**),  (**Home**), or  (**Work**). CapTel will dial the number automatically for you.
4. Lift the handset to dial.

TIP You can identify any contact person as a **“favorite”** for easy dialing. At the Add/Edit Contacts page, touch  (**favorite**). See page 84 for instructions.

Editing an Existing Contact

First: Mary
Last: Johnson
Mobile: 1-608-238-5400
Home: <touch to enter home number>
Work: <touch to enter work number>

favorite
speed dial

cancel
save

To make changes to a contact in your list:


1. From the display screen, touch (**Contacts**).
2. Under the Contacts list on the left side of display, find and touch the name of the contact you wish to edit. To see contacts further down the list, touch and drag the scroll bar. Information about the contact you selected appears on the right side of the display.

TIP Touch (**Next/Prev**) to move up/down through entries in your Contacts list.

3. On the right side of the display, touch (**Edit**) to go to the Add/Edit Contact screen.
4. Touch the field that you want to change, then use the on-screen keyboard to type in the new information. Touch the next field you want to edit, or move between fields by touching (**return**). Touch to erase the entire contents of a field.
5. When you are finished editing the contact, touch (**save**). The new contact information will be saved in your contact list.
6. When you are finished, press (**HOME button**) to exit.

TIP You can add a photograph of your contact person to each entry. Pictures can be entered at the MyContacts website, then synced to your phone. See *Adding a Photo to a Contact* on page 70 for instructions.

Removing a Contact




To remove a single contact from your list:

1. From the display screen, touch  (**Contacts**).
2. Under the Contacts list on the left side of the display, find and touch the name of the contact you wish to remove. Touch and drag the scroll bar to see contacts further down the list.

TIP Touch  (**Next/Prev**) to move up/down through entries.

3. On the left side of the display, touch  (**Delete**) to remove the person from your contacts.
4. CapTel asks you to confirm you want to delete the contact. Touch  (**yes**) to remove the contact or  (**no**) to exit.
5. When you are finished, press  (**HOME button**) to exit.

Adding a Contact to Speed Dial




You can set up to four (4) Contacts to be added to Speed Dial. Speed Dial entries appear every time you lift the CapTel handset, for quick one-touch dialing. You can even add photos to your Speed Dial entries for easy dialing by picture.

To add a Contact to Speed Dial:

1. From the display screen, touch  (**Contacts**).
2. In the Contacts list on the left side of the display, find and touch the name of the person you want to add to Speed Dial. To see contacts further down the list, touch and drag the scroll bar.

TIP Touch  (**Next/Prev**) to move up/down through entries.

3. On the right side of display, touch  (**Edit**). Touch  (**Speed Dial**).
4. If there are multiple phone numbers for this contact, the display asks which phone number (mobile, home, or work) you want to make a speed dial. Touch the number(s) you want, then touch  (**Accept**). A little graphic appears by the appropriate phone number to indicate it is added to Speed Dial.
5. Touch  (**save**).
6. When you are finished, press  (**HOME button**) to exit.

Now, when you pick up the handset, this contact will appear automatically on the display screen. Simply touch the person's name or image to dial.

TIP You can add a photograph of your contact person to each Speed Dial entry. See instructions on page 70.

Adding a Photo to a Contact



Using your computer, you can add photos to your Contact List to make it easy to dial by picture on your CapTel 2400i. You can also add, change, or delete Contacts on your computer, then download the changes directly to your CapTel 2400i phone.

Managing your Contact List is easy to do, but it takes two steps. First, go online and make changes at the MyContacts website. Then, “sync” with your CapTel 2400i to download the changes directly to your phone. Please see pages 71–81 for full instructions.

TIP *If someone helped set up your CapTel phone, you may want to consult with them as you manage Contact Lists on your computer.*

NOTE *If you do not have computer access, you can still add, delete, and change entries in your Contact List by using the touchscreen menu on the CapTel. Access to the MyContacts website is required, however, to add photos to your Contact List.*

Managing Your Contacts List

The MyContacts website helps manage the Contacts List on your CapTel phone. You can add new contacts, phone numbers, and even photos, then “sync” them with your CapTel 2400i.

NOTE


Because both the CapTel phone and the MyContacts website need to be set in sync mode, the sync process is easiest when the computer you are using and the CapTel phone are located close together. If the phone is in a different location than the computer, it may be helpful to have two people – one by the phone, one at the computer – to help the sync process go smoothly.

To manage your Contacts List:

1. On a computer that has Internet access, go to the website:
<https://MyContacts.CapTel.com>



2. The website asks “Would you like to create a new Contact List or load a previously saved Contact List?” Click on  (**Create New**).



Create New Contact List

Enter the name for your new Contact List.

Contact List Name:

Mom's Address Book

Create **Cancel**

3. Enter the name you would like to use for your new Contact List, then click on **Create** (**Create**).



4. Click on **Add Contact** (**Add Contact**).

A modal dialog box titled "Add Contact" with a dark header. The main area is light gray and contains the text "Please Enter a First and Last Name". Below this are two text input fields. The first is labeled "First Name:" and contains the text "Mary". The second is labeled "Last Name:" and contains the text "Johnson". At the bottom of the dialog are two buttons: "Save" and "Cancel".

Add Contact

Please Enter a First and Last Name

First Name:

Mary

Last Name:

Johnson

Save Cancel

5. Enter the first and last name of your contact, then click on **Save** (**Save**).
6. Add the phone number information for your contact. Use the tab key to move between fields. Click on **Save Contact** (**Save Contact**) when information is entered.

A screenshot of a web browser displaying the "CapTel MyContact Application" at the URL "https://mycontacts.captel.com". The page has a blue header with navigation tabs: "Contact List", "File", and "Sync Contacts". On the left is a sidebar titled "Mom's Address Book" with a search bar and a list of contacts, including "Mary Johnson". The main content area is titled "Edit a Contact" and contains form fields for "First Name" (Mary), "Last Name" (Johnson), "Mobile" (1 (808) 238-5400), "Home" (<Click to add>), and "Work" (<Click to add>). There is a placeholder for a profile picture with an "Add Photo" button. At the bottom of the main area is a "Save Contact" button. The footer of the page shows status for "Contacts" (1 used of 100 maximum), "Favorites" (0 used of 10 maximum), and "Speed Dials" (0 used of 4 maximum).

CapTel MyContact Application

https://mycontacts.captel.com

CapTel MyContact Application

Mom's Address Book

Search Contacts...

Mary Johnson

Edit a Contact

First Name: Mary

Last Name: Johnson

Mobile: 1 (808) 238-5400

Home: <Click to add>

Work: <Click to add>

Add Photo

Save Contact

Add Contact Delete Contact

Contacts 1 used of 100 maximum

Favorites 0 used of 10 maximum


Speed Dials 0 used of 4 maximum

To add a photo to this contact: click on **Add Photo** (**Add Photo**).



The website lets you browse your computer to select and save an existing photo. The photo files can be in jpg, png, or gif format.

Click on **Select Photo** (**Select Photo**), find and select the photo that you want to add.




Once your photo is selected, you may re-size or crop the image to fit nicely in the CapTel display window. Only the part of the image inside the green shaded box will appear on your CapTel display.

TIP

To resize your image, click and drag on the sidebar to make the image bigger or smaller. Click and drag the shaded box area to position it around your picture.

When you have a photo selected and sized, click on **Save** (**Save**).



When you are finished entering information for this contact, click on  **(Save Contact)**. The new entry appears in your Contact List on the left side of the MyContacts website (in alphabetical order by first name).

NOTE

*Making your contact a Speed Dial number lets you quickly dial-by-picture on your CapTel phone. Click on  **(speed dial)** to add this contact to your Speed Dial list. You may have up to 4 Speed Dial entries. You can also add this number to your Favorites list for easy dialing. To add this contact to Favorites, click on  **(favorite)**.*


7. Repeat steps 4–6 to add as many contacts as you'd like – up to 100 entries total.

8. When you are satisfied with your Contact List, you must Sync Contacts in order to save the list to your CapTel phone. Click on **Sync Contacts** (Sync Contacts), then select **Save Contacts to Phone** (Save Contacts to Phone).




9. The website asks you to select the Electronic Serial Number (ESN) for your CapTel phone. The ESN can be found **on your CapTel phone** by touching  (Contacts), then touching  (sync).

On your CapTel display screen:




At the MyContacts website:




Click on **Add New ESN** (**Add new ESN**), then enter the ESN from the CapTel display screen into the field labeled "ESN". Enter a name for the ESN in the field labeled "ESN Name". Click on **Add** (**Add**).

On your CapTel display screen:



10. At the window on your CapTel phone that says, "sync your contacts?" touch **accept** (**Accept**).


At the MyContacts website:




NOTE

Entries from your online Contact List are added to any contacts you may already have saved on your phone. If you would like to erase the existing contacts on your phone and replace them with the new Contact List from your computer, click on "Yes, Erase" on the MyContacts website before you start the sync process.

The website lets you know when the phone is ready to sync. Make sure the ESN you want is selected, then click on  **(Start Sync)** to begin the process.



Your Contact List is saved from the computer onto your CapTel phone. Watch on your CapTel phone display as the sync completes.





11. Once your Contact List is synced with your CapTel phone, you have the option to save your Contacts on your computer.

Saving a Contact List to your computer allows you to keep a back up and edit your list at a later time. You do not have to save your list on your computer – once the sync is finished, the Contact List is saved on your CapTel phone.

TIP *If you choose to save your Contact List, make note of where the xml file is saved on your computer for future reference.*

NOTE *Once the sync process is complete, your Contact List is saved on your CapTel phone. It will not change until you make changes on the phone or sync again with a different Contact List.*

12. Exit the MyContacts website by clicking on **Contact List** (**Contact List**), then selecting **Exit MyContacts** (**Exit MyContacts**).

Other options available at MyContacts.CapTel.com

Contact List

Under “Contact List”

Manage Favorites – Lets you add or delete contacts in your Favorites list. You can drag & drop any name from your Contact List on the left into your Favorites list.

Manage Speed Dials – Lets you add or delete contacts in your Speed Dial.

Manage ESN(s) – Lets you add or delete the Electronic Serial Number (ESN) of each CapTel phone.

Create a New Contact List – Lets you create a new Contact List. You can have multiple Contact Lists (i.e., one for business contacts, one for personal numbers, etc.).

Rename this Contact List – Lets you rename the current Contact List.

Exit MyContacts – To leave the MyContacts website. If any changes have been made, you can save the current Contact List to your computer. If you do not save, all information will be lost for security purposes. If the Contact List was already synced to your CapTel 2400i SPK, however, the information will already be saved on your phone.

File

Under “File”

Load Contacts from Computer – Opens any Contact Lists that you may have already saved on your computer, for you to edit or add new entries to.

Save Contacts to Computer – Lets you save a backup copy of the current Contact List to your computer. You can access the saved copy again at a later time to edit or add new entries.

Sync Contacts

Under “Sync Contacts”

Load Contacts from Phone – Brings the contacts you already have on your CapTel phone into the MyContacts website for you to edit or add photos to.

Save Contacts to Phone – Saves the current Contact List on the MyContacts website directly to your CapTel phone.

Favorites



This section tells you how to set your most frequently called Contacts as “favorites”, for quick dialing and dialing by photo.

TOPICS

- **About Favorites**
- **Adding a Contact to Favorites**
- **Dialing Favorites**
- **Removing a Contact from Favorites**

About Favorites



Favorites let you dial select numbers quickly and easily from the display screen. You can select any entries in your contact list to be included in your favorites list. You can save up to ten (10) phone numbers to your Favorites list.

NOTE

To add someone to your Favorites list, they must first be entered into your Contacts list. If you want to edit one of your Favorite's information, you must edit their entry in your Contacts list. See Adding a New Contact on page 65.

Adding a Contact to Favorites



You can save up to ten (10) numbers/entries to your Favorites list. To add a person from your Contact list to Favorites:

1. From the display screen, touch  **(Contacts)**.
2. In the Contacts list on the left of the display, find and touch the name of the person you want to add to Favorites. To see contacts further down the list, touch and drag the scroll bar or touch  **(Next/Prev)** to move up/down through entries.
3. Touch  **(edit)**.
4. Touch  **(favorite)**.
5. If there are multiple phone numbers for this contact, the display asks which phone number (mobile, home, or work) you want to make a favorite. Touch the number(s) you want, then touch  **(Accept)**. A little star appears by the appropriate phone number to indicate it is a favorite.

NOTE *If your Favorites list is full (10 entries), you need to remove a Favorite entry from the list first to make room in memory. See page 85 for instructions.*

6. Touch  **(save)**.
7. When you are finished, press  **(HOME button)** to exit.

Dialing Favorites

To dial a person in your Favorites list:

1. From the display screen, touch  **(Favorites)**.
2. Under the Favorites list on the left of display, find and touch the name of the person you wish to call.
3. On the right side of the display, touch  **(Call)**. CapTel dials the phone number automatically.
4. Lift the handset to dial.

Removing a Contact from Favorites

You can remove a person from your Favorites list. Deleting a person from Favorites does NOT delete them from your Contacts list.

To delete a person in your Favorites list:

1. From the display screen, touch  **(Favorites)**.
2. On the left side of the display, find and touch the name of the person you wish to delete.
3. Touch  **(Delete)**.
4. CapTel asks you to confirm that you want to remove this contact from Favorites. Touch  **(yes)** to remove the Favorite or  **(no)** to exit.
5. When you are finished, press  **(HOME button)** to exit.

NOTE

Removing a person from your Favorites list does NOT remove them from your Contacts list.

Settings



This section explains how to adjust settings on your CapTel to fit your preferences.


TOPICS

- **Setting the Language**
- **Switching Captions Language During a Call**
- **Setting the Display Brightness**
- **Screen Timeout**
- **Night Mode**
- **Network**
- **Saving Captions After Hang up**
- **Captions Button**
- **Ring Flasher**
- **Saving Conversation Volume**
- **Keypad Lights**
- **Setting the Ringer Volume**
- **Adjusting the Ringer Pitch**
- **Tone Control**
- **Time & Date**
- **About Your CapTel Phone**
- **Updating Your Software**
- **Advanced Settings**

NOTE

Directions for some settings are found in other chapters of this user manual.

Setting the Language



Your CapTel phone can display captions in English or in Spanish. Whatever language you select, the Options menu will also appear in that same language. The default setting is English. Spanish captions must be turned on in the CapTel settings menu in order for you to receive Spanish-language captions.

NOTE

Spanish captioning is available for Spanish-to-Spanish conversations only. The CapTel 2400i does not translate from English conversations to Spanish conversations, and vice versa.

To set the language:


1. From the display screen, touch  (**Settings**).
2. Touch  (**General Settings**).
3. Touch  (**Language**).
4. Touch  for English-language captions or touch  for Spanish-language captions.
5. Touch  (**Back**) when you are finished.

NOTE

In some multi-lingual households, you may want to switch between English-language captions and Spanish-language captions during the same call. If you think that might apply to you, touch the check box to select “Able to switch languages during a call”. If you anticipate your calls will only be in one language, either all in English or all in Spanish, do not check the box.

Spanish-to-Spanish captioning available everyday, 24/7.
For Spanish-language Customer Support: 1-866-670-9134

Switching Captions Language During a Call



NOTE

The Switch Language feature must be selected in order to change between languages during a call. The default setting is off. See page 87.

To switch captions language during a call:

1. The call will begin in whichever language is selected in the Settings menu.
2. If you need to switch the captions language while the call is in progress, touch  (**Opciones**), then touch  (**flags**). There will be a brief pause while your CapTel phone re-connects to the captioning service. Then captions will appear in the alternative language.

The call will be recorded in Call History as one call, even if you switch languages during the conversation.

When your call is completed (handset hung up), the captions language will go back to whichever language is selected in the settings menu.

NOTE

When the Switch Language feature is selected, you can set a default language for each person in your Contacts list. If a call comes in from (or is placed to) that Contact, the captions will automatically appear in the appropriate language.

Setting a Default Language for Contacts



When the Switch Language feature is selected, you can assign a default language for each person in your Contact list. When a call comes in from (or is placed to) that contact, captions appear in the appropriate language.

To set a default language for a contact:

1. Make sure the Switch Language feature is selected.
2. From the Contacts list, touch the contact you wish to change from the list on the left. The contact's information appears on the right.
3. Touch  (**Edit**).
4. Touch  (**Default Language**). The flag icon toggles between English and Spanish.
5. When you have the language you want, touch  (**save**).

Setting the Display Brightness

You can adjust the brightness of the display screen for easy reading in well-lit or dimly-lit areas. The display screen brightness changes as you move the setting so you can see what it will look like.

 **Settings** →  **Display** →  **Brightness**

Screen Timeout

As an energy-saving measure, your CapTel screen will start becoming more dim and gradually go complete dark after 60 seconds of non-use. Touching the display screen restores it to its original brightness. You can set how much time you want the screen to wait before becoming dim.

 **Settings** →  **Display** →  **Screen Timeout**

Night Mode

There may be times that you want your CapTel display to be at a darkened setting, called Night Mode. This is helpful, for example, in a bedroom at night when you don't need the bright display screen. You can set how long Night Mode stays on before the screen goes dark.

 **Settings** →  **Display** →  **Night Mode**

Network

If you use CapTel in a WiFi environment, the Network Setting shows you a list of all available WiFi networks within range, in order of the strongest signal strength to the weakest. You can change between WiFi networks or save common settings that you use most often.

 **Settings** →  **Network**

Saving Captions After Hang Up

You can set CapTel to save conversation captions after the call is over for later review, or to erase all captions each time the telephone is hung up. The default setting is Save Captions On.

 **Settings** →  **General Settings** →  **Save Captions On**

Captions Button

You can set the CAPTIONS button to automatically stay on or to automatically stay off at the beginning of every call. The default setting is Captions ON. If the CAPTIONS button is set to OFF, captions will not come on automatically. You must press the CAPTIONS button manually in order to turn captions on.

 **Settings** →  **General Settings** →  **Captions Button on**

Ring Flasher

CapTel includes a bright Ring Flasher that lights up to alert you every time a call comes in or whenever you have answering machine messages waiting. You can adjust the flash rate of the Ring Flasher for different indicators. For example, the Ring Flasher can blink evenly to indicate an answering machine message and can pulse to indicate an incoming call. To adjust the Ring Flash patterns:

 **Settings** →  **General Settings** →  **Flasher Settings**

Saving Conversation Volume

Your CapTel phone amplifies the voice of the caller up to 40dB. Every time you hang up the phone, the volume returns to a mid-range setting. You can set CapTel to remember the conversation volume setting so that it always stays at your desired volume level. The default setting is Save Volume Off.

 **Settings** →  **General Settings** →  **Save Volume**

Keypad Lights

The CapTel keypad lights up for easy dialing in dark environments. You can set the keypad lights to go off when your CapTel is not in use. When set to "off" the keypad lights will go off after approximately 30 seconds of non-use. The default setting is Keypad Lights On.

 **Settings** →  **General Settings** →  **Keypad Lights On**

Setting the Ringer Volume

You can turn the Ringer Volume up to a setting you hear best. The default setting is five (5). To turn the ringer off, select setting level zero (ringer muted).

 **Settings** →  **Sounds** →  **Ringer Volume**

Adjusting the Ringer Pitch

You can adjust the frequency of the CapTel ringer to a High, Medium, or Low range that you hear best. The default setting is Med.

 **Settings** →  **Sounds** →  **Ringer Pitch**

Tone Control

You can adjust the frequency of the sound coming through the CapTel handset to a frequency range that you hear best. Select from Low, Medium, High, or Customizable Frequency Ranges. To customize the frequency range, see page 29 for instructions.

 **Settings** →  **Sounds** →  **Tone**

Time Zone

You can adjust the time and date displayed on your CapTel phone screen based on your Time Zone. Touch the area on the map for the Time Zone that you live in. Be sure to indicate if your Time Zone practices Daylight Savings Time (DST).

 **Settings** →  **Time and Date**

About Your CapTel Phone

Provides details about how your CapTel phone is set up to help with troubleshooting issues.

 **Settings** →  **Info**

Updating Your Software

You can download the most current version of CapTel software to your phone. Once the download is complete, your CapTel phone will re-boot as part of the update process. Software downloads are encrypted for optimal security.

 **Settings** →  **Info** →  **Update**

Advanced Settings

Dynamic or Static IP

Using a Dynamic IP address (DHCP) is recommended to avoid IP conflicts. Some networks do not allow DHCP. In those cases, a Static IP address may be used. The default setting is Dynamic IP.

 **Settings** →  **General Settings** →  **Advanced Settings**
→  **Dynamic or Static IP**

Review Captions on Hang Up

You can set your CapTel phone to automatically go to conversation review mode after you hang up. This allows you to review the previous conversation(s) immediately after every call without using the Menu system. The default setting is off.

 **Settings** →  **General Settings** →  **Advanced Settings**
→  **Review Captions on Hang Up**

Voice Activity Detector

The built-in answering machine allows one minute for your callers to leave a message. In some cases, your callers' messages may be shorter than one minute. You can set the answering machine to hang up the telephone line once the incoming caller stops talking (stops leaving their message) instead of waiting the full one minute. The default setting is off.

 **Settings** →  **General Settings** →  **Advanced Settings**
→  **Voice Activity Detector**

Troubleshooting

Power Reset

On occasion, issues with your Internet connection may impact your CapTel phone. For example, you may have experienced times when your Internet seems to get “hung up” or things don’t look correct on your computer screen. These cases can sometimes impact how your CapTel phone operates. To correct, you may need to “reset” your CapTel phone, the same way you might “reset” your computer.

To Reset: Briefly unplug CapTel phone from the power adapter, wait 10 seconds, then plug it back in. The display screen lights up while the phone powers up. Then the display automatically takes you through the set-up steps again, asks you to confirm your language choice, checks your Internet connection, and confirms your time/date zone. CapTel will also check to make sure you have the most current software, and download any updates as needed.

Using Flash Option



Some telephone services like Call Waiting require a “hook flash”. The hook flash is a very brief interruption of the connection, like hanging up the phone for one second. There is a brief click or silence on the line. If you are on a call and see [beep] in the captions, you may have another call coming in. Touch the Options icon on the screen, then touch the FLASH icon once to pick up the incoming call (the current call goes on hold). Touch Options then the FLASH icon again to return to the original call.

To use Flash option during a call:

1. On the display screen, touch  **(Options)**.
2. Touch  **(Flash)**.
3. Touch  **(Back)** when you are finished.

CAPTEL 2400i SP-NBT INDEX

Answering a call.....	25	Captions.....	4, 9, 34-44, 52, 91
with captions	25	button.....	6, 9, 91
Answering Machine.....	51	change font color	41-42
erase messages	54, 55, 56	change font size and style.....	43
play messages	54	erase	40
play messages aloud/silent	63	how captions scroll	44
record personal greeting.....	57	In Spanish.....	12, 87-89
remote message retrieval.....	59	preference, method of captioning...	21
see captions.....	52, 54, 63	review after a call.....	38
set number of rings	62	review captions of previous call.....	48
turn on/off.....	53	review during a call.....	37
Buttons.....	8, 9	save captions after hanging up.....	39
captions	6, 9	switching captions method.....	26
customer service.....	6, 9	turn on/off.....	35
dialing keypad	6, 8	Contacts.....	64
home.....	6, 8	add from Call History	49
mute.....	6, 9	add new	65
speaker	6, 8, 30-31	add picture to contact.....	70, 71-81
volume	6, 8	dial from.....	66
Calls	22	editing	67
make/answer calls.....	22-27	erase a contact	68
use Call History	49	Conversation Memory	39
Call History	46	Corrections	36
adding contact from	49	Customer Service button	6, 9
delete.....	50	calling for help.....	back cover
dial from.....	49	Spanish customer	
review calls	47	service.....	87, back cover
review captions from call	48	Dialing	23
Call waiting.....	95	by picture	70, 71-81
		from Call History	49
		from Contact list	74
		from Favorites.....	85
		from number keypad	23
		with Speed Dial	69

Display Screen	6, 44	Personal identification	
adjust brightness.....	45, 90	number (PIN).....	59-60, 61
night mode.....	90	Power Reset.....	95
screen timeout	45, 90	Reading captions.....	34
Flash option (hook flash)	95	after hang up	38
Flasher	90	during a call.....	37
set the ring flasher	90	from previous call.....	48
Indicator Lights	8	Redial	24
on keypad	92	Remote Message Retrieval.....	59
mute.....	9	accessing message remotely	61
ring flasher	91	personal identification	
volume	8, 27	number PIN	59-60, 61
Internet	11, 13-17	remote access commands	60, 61
connecting to the Internet.....	13	turning on/off	59
requirements	11	Reset.....	95
using a router.....	13, 14	Ringer	92
using WiFi.....	15	adjust pitch.....	92
Keypad	6, 8	adjust volume	92
dialing from	23	ring flasher.....	7, 91
lights	92	turn ringer off	92
Language	12, 87-89	Ring flasher.....	7, 91
English.....	12, 87-89	Scroll, captions across display	44
Spanish.....	12, 87-89	smooth scrolling	44
Messages, Answering Machine	51	word-by-word scrolling	44
erase messages	54, 55, 56	Settings	86-94
play aloud/silent	63	Setup.....	11
play messages	54	help with set up	back cover
Mute button.....	6, 9	requirements	11
Network	13	using a router.....	13, 14
available networks.....	16, 90	using wireless/WiFi	15-17
change settings.....	16, 90	SmartCaptions.....	21
view saved networks.....	90		
WiFi.....	15		

Sound	28, 29	Time Zone	17, 93
adjusting on the speakerphone	27	Tone Control	28, 29, 93
adjusting the sound quality	28, 29	customize Tone setting	29
Spanish	12, 87-89	Troubleshooting	95
captions	12, 87-89	Updating your software	93
customer service		Volume	8
in Spanish	95, back cover	adjust during a call	27
Speaker button	6, 8, 36-37	button	6, 8
Speakerphone	30	Ringer volume	92
ending a call	31	save conversation volume	92
turning on/off	30	WiFi/Wireless network	15-17
Speed dial	69	enter network manually	16
adding contact to	69	view networks	15-16, 90
adding picture to	70		
dialing from	69		

FCC Information

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. A label is located on the underside of the CapTel containing, among other information, an ACTA Product-Labeling Number, US:D8KTE00BCAP2400. If requested, this number must be provided to the telephone company.

Should you experience trouble with this telephone equipment, please contact:

CapTel Customer Service
450 Science Drive
Madison, WI 53711
Phone: 888-269-7477 V/TTY
Email: CapTel@CapTel.com

For repair or warranty information, please contact CapTel Customer Service at 1-888-269-7477 (V/TTY).

The CapTel telephone does not have any user-serviceable parts. Modification or changes to the CapTel not expressly approved by Ultratec, Inc. can void your authority to operate the equipment.

Compliance Statement (Part 15.19)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning (Part 15.21)

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement (Part 15.105b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15B of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure (OET Bulletin 65)

To comply with FCC/IC exposure requirements for mobile transmitting devices, this transmitter should only be used or installed at location where there is at least 20 cm separation distance between the antenna and all persons.

To comply with FCC/IC RF exposure limits for general population/uncontrolled exposure, the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

Privacy Policy

A copy of the CapTel Privacy Policy is available for you to review online at www.CapTel.com/Privacy or you can request a printed copy by calling 1-877-464-9149.

FEDERAL LAW PROHIBITS ANYONE BUT REGISTERED USERS WITH HEARING LOSS FROM USING INTERNET PROTOCOL (IP) CAPTIONED TELEPHONES WITH THE CAPTIONS TURNED ON. Automatic speech recognition software generates captions of what the other party to the call says, and, in certain circumstances, a live communications assistant may be included on the call to make needed corrections and/or add call details. The captions are then sent to the phone. There is a cost for each minute of captions generated, paid from a federally administered fund. No cost is passed on to the CapTel user for using the service.

Getting Help

If you have any questions as you use your new CapTel 2400i, we're here to help. Use any of these ways to contact us:

Pick up the handset and press  (**CUSTOMER SERVICE button**) to automatically speed dial directly to our helpful Customer Service team. If you are in an office setting, you may need to dial a number such as "9" first to get an outside line first and then press  (**CUSTOMER SERVICE button**). *(Available 24 hours a day, 7 days a week. Customer Service is closed on major holidays.)*

Help materials are also available online at our website.



Phone: 1-888-269-7477 *(Available 24 hours a day, 7 days a week)*

FAX: (608) 204-6167



Mail: CapTel Customer Service
450 Science Drive
Madison, WI 53711



Email: CapTel@CapTel.com

Online: www.CapTel.com
(Live Chat help available at our website)

Spanish Language Customer Service: 1-866-670-9134

CapTel is the latest innovation from  **Ultratec**.

Ultratec, Inc.

450 Science Drive

Madison, WI 53711

(888) 269-7477 V/TTY

(866) 670-9134 (Spanish CapTel Customer Service)

Email: CapTel@CapTel.com • Fax: (608) 204-6167 • Online: www.CapTel.com

©2016-2026 Ultratec, Inc. All rights reserved.

Ultratec and CapTel are registered trademarks of Ultratec, Inc.

Other trademarks and trade names are property of their respective owners.